

BOAT & ENGINE PROCEDURES AND INFORMATION:

Opening:

- 1. Check weather forecast
- 2. Make sure you have your cell phone with you (and charged)
- Open boat
- 4. Secure hatches and sail cover down below
- 5. Check bilge and pump out if necessary
- 6. Rig complete boat
- 7. Ensure all safety equipment is onboard, accessible and operational
- 8. Keep chart and boating documents handy
- 9. Make sure dock line stays on the dock

Closing:

- 1. Secure boat to dock
- 2. Check all dock lines (2 bow and 1 stern)
- 3. Spring lines secured around the lower part of the chain plates (not the shrouds)
- 4. Ensure fenders are in proper/suitable locations
- Lay out sails to dry (if needed) and flake Flake mains!
- 6. De-rig rest of boat
- 7. Ensure all equipment is down below (winch handles!!)
- 8. Lift engine up and disconnect fuel line
- 9. Light scrub down (especially if anchoring was done)
- 10. Hang up life jackets and lines
- 11. Ensure nothing is left on cabin floor and remove all personal belongings and GARBAGE off boat
- 12. Does an accident/incident form need to be filled out? If yes file ASAP with Office
- 13. Close (and lock) boat
- 14. Halyards are to be coiled
- 15. Report repair issues ASAP to office via email info@advantageboating.com with "BOAT REPAIR" in subject line

In Case of an Incident/accident:

- 1. Apply appropriate first aid and ensure everyone onboard is safe
- 2. Fill out an incident/accident form and submit to office ASAP and send an email to info@advantageboating.com

Engines:

Check:

- If there is enough gas in the tank
- If the air valve on the gas tank is open
- If gas line is connected to the boat and the tank properly
- If the primer bulb (ball on the gas line) is hard
- If the kill switch is on properly
- If the gear selector is in the neutral position
- ON mercury motors if the engine switch (if so equipped) is turned to RUN/ON
- Turn throttle up slightly to give more gas when starting, especially if motor is flooded
- If the spark plug cables are secure

Sonars

- Tohatsu 4-Stroke Engine (STRAIGHT GAS)
- Do not tilt or lift up.

Tanzers

- Mercury 2-Stroke Engine 50:1 mixture Gas:Oil
- Engines lifted up when sailing or docked

Sharks

- Mercury 2-Stroke Engine 50:1 mixture Gas:Oil
- Engines when sailing → stored in lazarette or can be tilted
- Engines when docked → stored in lazarette when docked